




# BS 60H

## 12VOLTS POWER SUPPLY WITH BATTERY BACK-UP & CLOCK TIMER

### INSTALLATION AND WIRING

Remove the 3 screws from the sides and from the centre of the top cover, use the wiring access hole for the wires.

Use the holes at the bottom of the casing for mounting the power supply on the wall.



MOUNTING INSTRUCTION

#### FUSES

F1	Primary fuse 0.315 amp
F2	Secondary fuse 2 amp

Output	Voltage
1	12 V~
2	12 V~
3	contact H
4	contact H
5	- 12 V= (back-up voltage)
6	+12 V= (back-up voltage)
7	230 V~
8	230 V~

Do not forget to connect the wires to the battery !